




SAFETY FIRST!

Operation & Maintenance Manual C Series Compactor

Standard Model PSR Model



Rotobale Compaction Solutions Inc.

7232 Arthur Road #5 West, Kenilworth Ontario, NOG 2E0 Ph: 800-565-8027/ Fax: 519-323-3816

www.rotobalecompaction.ca

Rotobale Compaction Solutions Inc.

Kenilworth, Ontario, N0G 2E0 Tele (519) 323-3673 Fax: (519) 323-3816

Model C- Compactor

Operation Manual

TO TURN ON COMPACTOR: Insert the key in the switch and turn it right to the "on" position. If the "power on" light does not illuminate, disengage the emergency stop button (see below) and push start. If the "power on" light still does not illuminate but the "full" light is on; the container needs to be emptied. Turn the key to the "OFF" position when the compactor is not in use. (standard)

EMERGENCY STOP BUTTON: Press to stop the compactor. The compactor will remain in the 'off' mode until the emergency stop button is disengaged. To accomplish this; gently pull out on outer edge of the button. The emergency stop button plunger will pop out and the "power on" light will illuminate, allowing the compactor to be started.

75% FULL LIGHT: This light will blink when the ram is traveling forward and pressure inside the charging chamber reaches a preset limit (around 1,000 psi).

FULL LIGHT: When pressure inside the charging chamber reaches a preset limit, (around 1,500 psi), the "full light" will illuminate and the compactor will shut off. The container needs to be emptied

RESET: Turns off the "full light" and resets the system to enable start.

REVERSE BUTTON: Used to put ram in reverse.

PRESSURE GAUGE: (Optional) Indicates compaction pressure.

TIMER: (Optional) Will allow the ram to continuously run through a preset number of complete cycles before the machine shuts off.

AUTOMATIC RUN TIMER: (Optional) will allow the compactor to start automatically at preset Timed interval.

PHOTO EYE: (Optional) will allow the compactor to turn on automatically when debris is placed into ram chamber to a preset height most often from conveyer.

Rotobale Compaction Solutions Inc.

Kenilworth, Ontario, N0G 2E0 Tele (519) 323-3673 Fax: (519) 323-3816

Model C- Compactor Maintenance Manual

Hydraulic System:

The manufacturer recommends regular inspection of all hoses and visual inspection of hydraulic components. All inspections must be done with compactor disabled. By doing so the user becomes more familiar with the compactor, which in turn guarantees early detection of possible problems (E.g.: leaks). When inspecting hoses look for cuts, abrasions and fluid. Look for leaks at and around the 'power pack', at all hose connections and inside the rear of the compaction chamber. If any hydraulic fluid is visible, the user should contact the manufacturer. The hydraulic fluid level in the power pack reservoir should be maintained at 2" from the top of the tank, with the ram in the rear position. Only a qualified technician should service any components in the hydraulic system.

Lock Out Procedure:

NOTE: Only qualified technician should perform electrical work on these machines.

The person working on these machines should turn the machine off with the stop button. To turn off and lockout the power supply, follow the electrical supply cord from the machine to the disconnect box on the wall. This box should be located within 30 feet of the machine. Pull the handle down or turn the switch to the "off" position to shut off the electricity. Put a padlock through the holes of the handle or switch and lock it so that it cannot be turned on without removing the lock. Only the person locking out the machine should have a key for the padlock. If more than one person is involved, the person who disconnected and locked out the power supply should communicate the purpose and status of the disconnecting and locking out. A non-conducting tag secured in a conspicuous location may serve this purpose. For more guidelines concerning this procedure, refer to the "Occupational Health and Safety Act and Regulations for Industrial Establishments" section 42.

Warranty:

All equipment designed and manufactured by Rotobale Compaction Solutions Inc. (RCS) carries a (1) year parts and labour guarantee. A Rotobale waste system is constructed of high-grade materials and is guaranteed to perform on a continued basis at its rated capacity. Any parts that prove defective within (1) year from the date of installation will be replaced without charge, provided the purchaser notifies any such defects to RCS.

Some units may be purchased with extended warranties.

Voiding of Warranty:

If the contents of this manual are explicitly followed, the operation of the Rotobale waste system is guaranteed. If however operations are performed in a matter not in accordance with these instructions and a defect appears in the waste system, the owner shall make void the warranty that accompanies their Rotobale machine. In addition, defects resulting from service work not authorized by RCS, shall render the warranty void.

Declaration of Conformance Pre-Start Health and Safety Review Exemption

Machine Name:	Stationary Compactor
Machine Model:	4260 and C-Series (4260 / C-16 / C-22 / C-26)

Based on the safety component installation instructions and electrical drawings provided, the above items are in compliance with the following standards;

Description	Standards requirement met for compliance		
	Is in accordance with the manufacturer		
Safety control circuit design	requirements and CSA Z432, Clause 8.2 Safety		
	control system performance criteria.		
	Is in accordance with NFPA 79 Electrical Standard		
Emergency stop	for Industrial Controls, Clause 9.5.2 Stop		
	Functions – Category <0,1>		

Rotobale Compaction Solutions Inc declares that the above noted machine has been designed and constructed in accordance with the following standards:

- CAN/CSA Z432-16 Safeguarding of Machinery
 - ISO 13849-1 Safety of machinery Safety-related parts of control systems Part 1:
 General principles for design
- CAN/CSA C22.1 Canadian Electrical Code, Part 1
- SPE-1000 Model Code for the Field Evaluation of Electrical Equipment

Rotobale Compaction Solutions Inc also declares that the protective elements employed on this machine have been installed according to the manufacturer's instructions.

This document can be used as a declaration that forms a Pre-Start Health and Safety Review Exemption as required by Ontario Regulation 851, Section 7, subsection 10.

This document must be kept readily available in the workplace for as long as the protective element remains or is used in the workplace.

Rotobale Compaction Solutions


7232 Arthur Side Road # 5 West, Kenilworth, Ontario N0G 2E0


Tele: (519) 323-3673 Fax: (519) 323-3816

7232 Arthur Side Rd. #5 West | Kenilworth, Ontario | NOG 2E0 Phone: 519-323-3673 | Fax: 519-323-3816 |Toll Free: 1-800-565-8027 Email: info@rotobalecompaction.ca Website: www.rotobalecompaction.ca

RC, 4260 & C Series Compactor - Annual Inspection Report


Customer Name	Inspection D	Inspection Date:		
Make/Model of Equipment		Inspected by	<i>7</i> :	
Serial #				
Powerpack Electrical Inspection Points	Good	Needs Repair	Comments	
Check Key Switch				
Check Reset & Reverse Buttons				
Check Emergency Stop Button				
Check all Indicator Lights				
Check Door & Gate Switches (if appl.)				
CAUTION LOCK OUT / TAG OUT				
Check all Electrical Connections in Panel are Tight				
Check all Timers are Secured to Base				
Check Main Supply & Control Fuse Sizing				
Powerpack Hydraulic Inspection Points	Good	Needs Repair	Comments	
Check Pump, Suction & Pressure Hoses	Good	recus Repair	Comments	
Check Main Valve for Leaks				
Check Relief Valve for Leaks				
Check Oil Level				
(Down 2" from top of tank when ram up)				
Compactor Inspection Points	Good	Needs Repair	Comments	
Check Scraper, Slider & Ram	Good	recus repair	Comments	
Check Cylinder Shaft & Pins are Secure				
Check Cylinder Extend, Retract Hoses				
Check Back Charge Box clear (RC Only)				
Check Cylinder Cover Secure (RC/4260)				
Check Hydraulic Fittings on Side for Leaks				
Check Arm Clamps (Non RC Only)				
Check all Visible Anchor Points (Chute/Encl)				
Check Foam Building Seals (if Appl.)				
Check Foahi Building Seals (II Appl.)				
Container Inspection Points	Good	Needs Repair	Comments	
Check & Grease all Wheels				
Check Door Latching Assembly				
Check Door Seal (RC Only)				
Check Door Chain & Latch				
Check & Grease Ratchet Loadbinder				
Check & Grease Ratchet Arm Lock (if Appl.)				
Check & Grease Door Hinges				
Check Compactor Rails & Guide Island				
Check all Pull Hooks				





ROTOBALE COMPACTION C -16 HYDRAULICS

DESCRIPTION
B- CYLINDER HOSE
A- CYLINDER HOSE
SUCTION HOSE
P - HOSE
PRESSURE GAUGE HOSE
MOTOR 10 HP
COUPLING
BELL HOUSING
HYDRAULIC PUMP
RAM CYLINDER
DUMP VALVE
RAM VALVE
RAM MANIFOLD
MAIN RELIEF



C - 22 HYDRAULICS

	PARTS	DESCRIPTION		
	HOSES			
	1)@ $\frac{3}{4}$ X $36\frac{1}{2}$ X $\frac{3}{4}$ ENDS	B- CYLINDER HOSE		
	1)@ ½ X 88 X ½ ENDS	A- CYLINDER HOSE		
	1) @ 1" X 26 1" ENDS	SUCTION HOSE		
	1) @ ½ X 18 ½ ENDS	P - HOSE		
	1) @ ¼ X 30 X ¼ ENDS	PRESSURE GAUGE HOSE		
7	215 FRAME 1800 RPM	MOTOR 15 HP		
	R 100 1 ³ ₈ X ⁵ ₈	COUPLING		
	A-MOUNT 5-5	BELL HOUSING		
	HAIR 22 - 15 G.P.M.	HYDRAULIC PUMP		
	1) CYLINDER @ 6 X 78	RAM CYLINDER		
	VALVE - 85003093	DUMP VALVE		
	VALVE - D4 - 03 156 AC 110	RAM VALVE		
	MANIFOLD ROTOBALE # 5	RAM MANIFOLD		
	RELIEF 85002129	MAIN RELIEF		
		B line PRESSURE SWITCH GAUGE secondary dump valve anti knock T line		

C - 26 HYDRAULICS

PARTS	DESCRIPTION		
HOSES			
1)@ ³ / ₄ X 36 ¹ / ₂ X ³ / ₄ ENDS	B- CYLINDER HOSE		
1)@ ½ X 120 X ½ ENDS	A- CYLINDER HOSE		
1) @ 1" X 26 1" ENDS	SUCTION HOSE		
1) @ ½ X 18 ½ ENDS	P - HOSE		
1) @ ¼ X 30 X ¼ ENDS	PRESSURE GAUGE HOSE		
215 FRAME 1800 RPM	MOTOR 15 HP		
R 100 1 ³ ₈ X ⁵ ₈	COUPLING		
A-MOUNT 5-5/8	BELL HOUSING		
HAIR 22 - 15 G.P.M.	HYDRAULIC PUMP		
1) CYLINDER @ 6 X 108	RAM CYLINDER		
VALVE - D4 - 03 156 AC 110	RAM VALVE		
MANIFOLD ROTOBALE # 5	RAM MANIFOLD		
RELIEF 85002129	MAIN RELIEF		
	B line PRESSURE SWITCH SGAUGE secondary dump valve anti knock T line		
OIL TANK	\Diamond		

Product Data Sheet

NOCO MULTI-PURPOSE EP#2

NOCO MULTI-PURPOSE EP#2 is compatible with the most popular greases in use today, including Aluminum complex, calcium, calcium complex and lithium grease. It is not compatible with barium Ben tone or poly urea greases.

NOCO MULTI-PURPOSE EP#2 is multi-purpose, premium quality grease made from high viscosity Index base oils and a lithium complex soap thickener system. Because of its outstanding performance Properties, it can be used for the lubrication of machinery under heavy loads and high temperatures in a wide range of automotive, industrial, agricultural, mining and construction applications.

NOCO MULTI-PURPOSE EP#2 can be used to lubricate plain ball and roller bearings in equipment Operating from slow to high speeds and at temperatures ranging from –24° C (15°F) to 170°C (365°F).

Typical Properties & Characteristics

Test Methods	Description	Specification
	NLGI Grade	2
ASTM D 217	Cone penetration @ 77°F, worked 60 strokes	265 - 295
ASTM D 128	Thickener Type	Lithium Complex
ASTM D 128	Thickener Content, %	4 - 7
ASTM D 2265	Dropping Point	168°C, (360° F)
ASTM D 445	Base Oil Viscosity, cut @ 40°C	175 - 180
ASTM D 2270	Viscosity Index	80 min.
VISUAL	Color	Dark Amber
VISUAL	Appearance	Smooth
ASTM D 2509	Timkin OK Load, lbs.	35 min

Don't Pollute! Dispose or used oil properly!

Call your NOCO sales representative for details on our Oil Recovery Program All reasonable care has been taken to ensure that the above information is accurate as of the date of printing.

NOCO Energy Corp. Tonawanda, NY 14150 (800) 500-6626

Product Data Sheet

NOCOLUBE AW SERIES

NOCOLUBE AW Series are premium hydraulic fluids formulated from high quality paraffinic base oils that meets severe pump requirements of all major manufacturers. NOCOLUBE AW Series provides outstanding anti-wear protection. The oils will provide excellent long service life under severe industrial and mobile hydraulic applications.

Typical Approvals

Vickers I-286-S, M-2950-S Cincinnati Milacron P-68, P-69, P-70 Denison HF-0 DIN 51524, Part 2 AFNOR NF-E 48-690/1 AFNOR E 48-603 HM ISO 11158 TYPE HM

GENERAL CHARACTERISTICS

NOCOLUBE AW	32	46	68	100	220
NOCOLOBL AW	32	40	00	100	220
Product Code	NOC1657	NOC1658	NOC1659	NOC2778	NOC2779
Appearance	Light Pale	Light Pale	Light Pale	Light Pale	Dark Pale
Flash Pt., COC °C	212	226	234	242	258
Pour Point, °C	-24	-24	-18	-15	-15
Viscosity					
CST @ 40°C	32.0	46.0	68.0	100.0	220.0
CST @ 100°C	5.4	6.7	8.5	11.1	18.7
Rust ASTM D 665B	Pass	Pass	Pass	Pass	Pass
Copper Strip Corrosion	1A	1A	1A	1A	1A
Oxidation Life (hours),	2500+	2500+	2500+	ND	ND
ASTM D-943					
Viscosity INDEX	104	104	107	95	93

FEATURES

- Outstanding Thermal Stability
- Long Service Life
- Superior Hydrolytic Stability
- Excellent Remissibility
- Low Pour Point
- Qualified Products

BENEFITS

- Reduces sludge and sticking problems in close tolerance components
- Provides superior system cleanliness with reduced oxidation
- protects against rust and corrosion
- Works well when, contaminated with a small amount of water.
 Readily separates large amounts of water
- Good low temperature performance
- Proven field performance


Don't pollute! Dispose of used oil properly!

Call your NOCO sales representative for details on our Oil Recovery Program.

All reasonable care has been taken to ensure that the above information is accurate as of the date of printing.


NOCO Energy CORP. Tonawanda, NY 14150 (800) 500-6626 DATE

16 / 03 / 2019



Standard Specification's Model C-16

Attached Bin	40		50	
WASTE WEIGHT AF	12 TON 15		15 TON	
RAM PENETRATION 14" (WITHIN CONTAINER)				
MOTOR	5 HP	5 HP 10 HP		10 HP
PUMP SIZE	5.2 GF	5.2 GPM 10.4 GPM		10.4 GPM
CYCLE TIME 90 SE		ONDS	4	45 SECONDS
VOLTS 208 / 5		575		208 / 575
AMPS 15 / 6		3		30 / 12




SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE


TO ACCOMODATE EQUIPMENT IMPROVEMENTS


ROTOBALE COMPACTION SOLUTIONS

PHONE 519-323-3673 FAX 519-323-3816

C-22 STATIONARY COMPACTOR







Standard Specification's Model C-22

Attached Bin	40		50	
WASTE WEIGHT AF	12 TO	N	15 TON	
RAM PENETRATION	1	17" (WIT	HIN C	ONTAINER)
MOTOR 5 H		10 HP		10 HP
PUMP SIZE 5.2		PM 10.4 GPM		10.4 GPM
CYCLE TIME 120 SE		CONDS	(50 SECONDS
VOLTS	208 / 9	575		208 / 575
AMPS	15 / 6	5		30 / 12

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE


TO ACCOMODATE EQUIPMENT IMPROVEMENTS

ROTOBALE COMPACTION SOLUTIONS

KENILWORTH, ONT, CAN, 7232, ARTHUR ROAD # 5, NOG 2EO

TEL: 519-323-3673 FAX: 519-323-3816

C-26 STATIONARY COMPACTOR




Standard Specification's Model C-26

Attached Bin	40		50	
WASTE WEIGHT AF	12 TON		15 TON	
RAM PENETRATION	17" (WIT	HIN C	ONTAINER)	
MOTOR 5 HP		10 HP		10 HP
PUMP SIZE 5.2		РМ		10.4 GPM
CYCLE TIME 150 SE		CONDS	1.4	75 SECONDS
VOLTS	208 / 5	575		208 / 575
AMPS	MPS 15 / (30 / 12

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE

TO ACCOMODATE EQUIPMENT IMPROVEMENTS

Please only use pins they will allow for flexibility from shifting and movement from ice and freezing in winter while maintaining good sheer strength



DRILL .750 CEMENT BIT ALL THE WAY THROUGH THE CEMENT TO ALLOW WATER TO EXCAPE SO CEMENT WILL NOT BRAKE IN WINTER AND PIN

